Fuse Replacement
DELTA/DELTAI

Fuse Replacement:

1. Twist the Fuse Holder cap.

2. Pull out the cap and replace the fuse.
   120V– 15 amp
   220V– 10 amp