

Blotter Instructions
HCL/HCLI

1. Place wet samples on several (4+) layers of paper towel. Place two layers over the samples and place blotter on the paper towel.
2. Set the Blotter on the samples for 2 to 3 minutes, then replace the paper towels and repeat process for an additional 2 to 3 minutes.
3. Place samples in the drying oven as per the procedure.

