




## Controller Replacement A200/A200I



1. Unplug the instrument and remove the back panel.
2. Remove all wires to the controller.
3. Spread both sides of the mounting clip apart on the controller and pull the mounting clip off the controller.
4. Pull the controller out of the cabinet.



5. Install the new controller and mounting clip.
6. Attach the wiring as shown in the pictures. The wiring diagram can be referenced in your A200/A200I/A220 Manual.