Service Procedure **008** (Page 1 of 1) 07/21/2014

Controller Replacement (Splat) XT10/XT10I, XT15/XT15I and HCI/HCLI

- 1. Remove the two screws securing the cabinet cover and open the compartment. Remove the four screw holding the plastic cover on circuit board using a small Phillips screwdriver.
- 2. Unplug the Splat connectors and the ribbon connector to the display. The plugs are color coded. Refer to the wiring diagram in your manual.
- 3. Use an adjustable wrench to remove the standoffs that hold the Splat board in place
- 4. Install the new board and secure with the standoffs that were removed in Step 3.



- 5. Use the wiring diagram as a reference to plug in the Splat connectors. Check to make sure they are in the correct location– you can burn out the board if they are not.
- 6. Attach the plastic cover to the standoffs and fasten the cover.
- 7. The instrument is ready for operation.