


LCD Brightness Adjustment XT10/XT10I and XT15/XT15I

Insert a small screwdriver into this button and rotate it to the right This will increase the brightness on the LCD Screen.



Inputs 0-3 Inputs 4-7 Power

Analog In Analog Out Outputs 0-3 Outputs 4-7